



Lighting Selection Guide

Sizing recommendations and tips for selecting decorative lighting

We understand sizing is tricky business, but our team is here to help. Visit your local Kendall Lighting Center showroom to work one-on-one with a trained lighting consultant. We always recommend confirming sizing, scale, and more in-person before finalizing selections. Find the showroom nearest you online at [kendalllightingcenter.com](https://www.kendalllightingcenter.com).

chandeliers

Chandelier Sizing—Dining Room Table

We suggest leaving approximately 30–36” between the bottom of the fixture and the table top.

NOTE: If you have tall ceilings, additional chain and or down rods can typically be ordered to allow your fixture to hang at the appropriate height.

A chandelier over a dining table should be approximately $\frac{1}{2}$ to $\frac{3}{4}$ the width of your table.

Example: If your dining room table is 48”W, a chandelier that is 24”–36” in diameter would be appropriate.



5113945 | Kichler Kitner 3 Light Linear Chandelier—Black

kitchen island

When selecting pendants or a singular fixture for over a kitchen island, it is recommended to leave approximately 30–36” between the bottom of the fixture and the surface top.

If using multiple pendants, it is recommended to space the fixtures around 30” apart.



303477 | Kichler 9.5” 1 Light Mini Pendant—Brushed Nickel

entry, hall, bedroom, great room

Hanging fixtures such as chandeliers, ceiling fans, or semi-flush fixtures should hang a minimum of 7' from the floor to the bottom of the fixture. This allows for taller guests and most standard doors to clear the bottom of the fixture.

The diameter of the fixture should be the length + width of the room in feet converted to inches.

Example: If your room is 10'x15' then the diameter of the fixture should be approximately 25". If your room is 12'x14' then the diameter of the fixture should be approximately 26".



236909 | Kichler Taubert 3 Light Foyer Pendant—Black

exterior lighting

Fixtures placed by an exterior door should be approximately $\frac{1}{4}$ the height of the door when using two fixtures and approximately $\frac{1}{3}$ the height of the door when using one fixture.

All exterior wall mounted fixtures should be installed with approximately 66" between the center of the fixture to the threshold of the door.



749175 | Kichler Atwood 14.25" 1 Light Wall Light—Brownstone

ceiling fans

In order to ensure your ceiling fan can distribute proper air flow, it is important to have the right size down rod.

9' ceilings: 12" or smaller

10' ceilings: 12-18" downrod

11' ceilings: 18-24" downrod

12' ceilings: 24-36" downrod

13' ceilings: 36-48" downrod

14' ceilings: 48-60" downrod

15' ceilings: 72" downrod

NOTE: If you are still unsure of the appropriate downrod length for your room, consult one of our on-staff lighting consultants.

All ceiling fans should have a minimum of 7' clearance from the floor to the fan blades.


It is important to consider the blade rotation of your ceiling fan. Most ceiling fans can be utilized in winter and summer months.

Photos provided by

KICHLER



5113763 | Kichler Seaside 54" 4 Blade LED Ceiling Fan



WINTER—Clockwise

Pulls warm air up and around. This causes the warm air to be forced back into the space.



SUMMER—Counter-Clockwise

Pushes cool air down to create a breeze/cooling effect.



See Yourself in a Better Light™

with the help of the professional lighting consultants at Kendall Lighting Center. Visit one of our premier showrooms to browse the latest trends in decorative lighting, home decor, outdoor lighting, and more.

Fort Wayne

4621 Executive Blvd
Fort Wayne, IN 46808
260-483-8820

Elkhart

725 Verdant St
Elkhart, IN 46516
574-389-3400

Warsaw

3910 Corridor Dr
Warsaw, IN 46582
574-269-3838

Grand Rapids

810 Scribner Rd
Grand Rapids, MI 49504
800-447-5493